Smart Client Operation Instruction

一、Installation

1 Click ![SmartClient Windows v1.0.1.29.exe SmartClient Setup] to begin to install Smart Client

2 Click [Next >] to continue

3 Select Destination Location

4 Select Additional Tasks

Desktop icon like this

5 Click [Install]

6 Click [Finish] to complete the installation of Smart Client

二、User Login

User Login

Number	Device Name	IP	Server Port
1	DVR	192.168.0.102	9000

Scan Device In LAN

Network Type
- ⦿ WAN
- ◯ LAN

Register Mode
- ⦿ IP Address
- ◯ Domain Name

IP
Server Port
User Name   admin
Password
Language   English
Auto Login   ☐

Login   Cancel

Select Language

Find Connected DVR   Search Connected DVR

User Login

Number	Device Name	IP	Server Port
1	DVR	192.168.0.102	9000

Scan Device In LAN

Network Type
- ⊙ WAN
- ○ LAN

Register Mode
- ⊙ IP Address
- ○ Domain Name

IP
Server Port
User Name   admin
Password
Language   English
Auto Login   ☐

Login   Cancel

Select and click connected DVR, then click [Login] to login

5YUX_pcd. . .

User Login

Number	Device Name	IP	Server Port
1	DVR	192.168.0.102	9000

Scan Device In LAN

Network Type
- ○ WAN
- ⊙ LAN

Register Mode
- ⊙ IP Address
- ○ Domain Name

IP   192.168.0.102
Server Port   9000
User Name   admin
Password
Language   English
Auto Login   ☐

Login   Cancel

Smart Client user login UI is similar to IE user login UI

Preview Playback Setup

- Channel01
- Channel02
- Channel03
- Channel04
- Channel05
- Channel06
- Channel07
- Channel08

Start time 2012-12-20
0:00:00
End time 2012-12-21
23:59:59
Type All

File name	S
0120121220154317	2(
0120121220155514	2(
0120121220155959	2(
0120121220165959	2(
0120121220172715	2(
0120121220180000	2(
0120121220190000	2(

20/12/2012 15:43:19 THU

Camera1

1/8x 1/4x 1/2x 1 2x 4x 8x

Preview Playback Setup

Local Config

Remote Config

Local Config

Record Path   C:\RecordFile   Browse

Download Path   C:\DownloadFile   Browse

Snapshot Path   C:\Capture   Browse

Convert to AVI   ☐

Auto Login   ☐

Save